

Device Type Table

Device Type	Device Name	Letter Representation	Wireless Link OSD
0	TV	T	T
1	Cable	C	Cable Box
2	Video Accessory	N	N
3	Satellite/DSS	S	Satellite
4	VCR	V	VCR
5	Digital Video Disc	Y	DVD/BD
6	Tuner	R	Receiver
7	Amplifier	AM	AM
8	Compact Disc	D	D
11-15	Reserved	Reserved	Reserved



Table of Contents

Cable Box

Setup Codes For Cable Set Top Box (C)	Pg. 3-5
Cable/PVR Combination (C)	Pg. 5

Receiver

Setup Codes For Audio - Receiver (R)	Pg. 6-11
--------------------------------------	----------

Satellite

Setup Codes For Satellite Set Top Box (S)	Pg. 11-21
SAT/PVR Combination (S)	Pg. 21-23

VCR

Setup Codes For Video - VCR (V)	Pg. 23-38
DVD/VCR Combination (V)	Pg. 38-40
PVR (V)	Pg. 40-41
HDD/DVD Combination (V)	Pg. 41
SAT/PVR Combination (V)	Pg. 42

DVD

Setup Codes For Video - DVD (Y)	Pg. 42-57
DVD-R (Y)	Pg. 57-60
DVD/VCR Combination (Y)	Pg. 60-63
HDD/DVD Combination (Y)	Pg. 63-64

DVD

Blu-ray Disc (Y)	Pg. 64
------------------	--------

Wireless Link IR Code List

Setup Codes For Cable Set Top Box (C)

Cable Box

ABC	0237, 0003, 0008, 0033
ADB	2586
Amino	1822
British Telecom	0003
Cable & Wireless	1068
Cisco	0877, 1877
Comtec	0019
Contec	0019
Daeryung	0877, 1877, 0477, 0008
Digeo	1187
Director	0476
DX Antenna	1500, 1502
France Telecom	0817
Freebox	1482, 1976
Fujitsu	1497
Funai	0019
Galaxi	0008
GE	0237
Gehua	0476
General Instrument	0476, 0810, 0003
GoldStar	0144
Hamlin	0273
Hitachi	0033
Humax	1813, 1981, 1983
Jerrold	0476, 0810, 0003
Kabel Deutschland	1981, 1983
Kabelvision	0003
KNC	0008
LG	0144
Macab	0817
Macom	0033
Maspro	1510
Melita	0003

Wireless Link IR Code List

Setup Codes For Cable Set Top Box (C).....Continued

Memorex	0000
MNET	0019
Motorola	1376, 0476, 0810, 1187
Multichoice	0019
Myrio	1822
NEC	1496
Noos	0817
NTL	1068, 1060, 0003
Oak	0019
Ono	1068
Optus	1060
Orange	0817
Pace	1877, 0237, 1068, 1060, 0008, 1577
Panasonic	0000, 0107, 0008, 1488
Paragon	0000
Philips	0817, 1582, 1619
Pioneer	0877, 1877, 0144, 0533, 1500, 1782
Pulsar	0000
PVP Stereo Visual Matrix	0003
Quasar	0000
Regal	0273
Runco	0000
Sagem	0817
Salora	0000
Samsung	0000, 0144, 1060, 1666, 2015
Scientific Atlanta	0877, 1877, 0477, 0237, 0008, 1510
Sony	2177
Starcom	0003
Sumitomo	1500
Telenet	1920
Telewest	1068
Thomson	1582, 1981, 1983
Time Warner	1877

Wireless Link IR Code List

Setup Codes For Cable Set Top Box (C).....Continued

Cable Box

Tocom	0059
Torx	0003
Toshiba	0000, 1509
TS	0003
United Cable	0003
UPC	1582
Virgin Media	1068, 1060
Visiopass	0817
Zenith	0000, 0525, 0008

Wireless Link IR Code List

Cable/PVR Combination (C)

Cable Box

Amino	1822
Cisco	1877
Digeo	1187
Freebox	1482, 1976
General Instrument	0810
Humax	1813, 1981, 1983
Jerrold	0810
Motorola	1376, 0810, 1187
Myrio	1822
Pace	1877, 0237
Philips	1619
Pioneer	1877
Scientific Atlanta	1877
Telenet	1920
Time Warner	1877
UPC	1582

Wireless Link IR Code List		Receiver
Setup Codes For Audio - Receiver (R)		
ADC	0531	
AEG	1389, 1390	
AFK	1389	
Aiwa	0121, 1089, 1641	
Akai	0609, 1390	
Alco	1390	
All-Tel	1390	
AMC	1077	
Amstrad	0744, 1390	
Anam	1609, 0609	
Arcam	1189, 1212	
ASCOMTEC	1389	
Audio Control	1212	
Audiolab	1189	
Audiosonic	1389	
Audiotronic	1189	
Audiovox	1390	
Audioworld	1390	
B & K	0820	
Bang & Olufsen	0799	
Belson	1389	
Binatone	1389	
Blue Sky	1390	
Bose	1229, 0639, 1933	
Bush	0797, 1772	
Cambridge Audio	1647	
Capetronic	0531	
Carver	1189, 0121, 1089, 1289	
Cat	1389	
Celestial	1412	
Centrum	1389	
Clatronic	0797, 1389	
Coby	1389	

Wireless Link IR Code List

Setup Codes For Audio - Receiver (R).....Continued

Receiver

Cosmotron	0797
Curtis	0797
Daewoo	1250, 1293
Dantax	0463, 1390
Denon	1360, 0121, 1104, 1142, 1306, 2857
Denver	1389
Diamond	1390
Digeo	2857
Digitech	1772
DiK	0797
Dual	1390
DVX	1772
eBench	0744, 0797
Elta	0744, 0797, 1390
Ferguson	0531, 1154
Fine Arts	1189
Firstline	0797
Fisher	1801
Fonmix	1360
Garrard	0463, 0744
Genexxa	0186
Goodmans	0609, 0744, 0797, 1389, 1390
GPX	0744
Grundig	1189, 0797, 1089, 1772
Grunkel	0744, 1390
Hanseatic	1390
Harman/Kardon	1189, 0110, 1289, 1304, 1306, 1310
Harwood	0744
HCM	1390
HE	1389
Hitachi	1801
Hitech	0744
Hiteker	1389

Wireless Link IR Code List

Setup Codes For Audio - Receiver (R).....Continued

Receiver

Home Tech Industries	1389
Inkel	0491, 0502
Insignia	1077
Integra	1298, 1320, 1805
Intersound	0744
JBL	0110, 1304, 1306
JVC	0074, 0531, 1374, 1495
Kenwood	1313, 1569, 0186
Kioto	0797
KLH	1390, 1412, 1428
Kompernass	0797
Koss	0744
KXD	1389
Lenox	1389
LG	1293
Lifetec	0797
Lumatron	1772
Luxman	0463
LXI	0744
Magnat	1389
Magnavox	1189, 1269, 0128, 0391, 0531, 1089, 1514
Marantz	1189, 1269, 0128, 0744, 1089, 1289
Matsui	0744, 0797
McIntosh	1289
Medion	0797
MEI	1390
Micromega	1189
Microstar	0797
Mitsubishi	1393
Mivoc	1508
Musicmagic	1089
Mx Onda	0744, 0797
Myryad	1189

Wireless Link IR Code List

Setup Codes For Audio - Receiver (R).....Continued

Receiver

NAD	0320, 0609
Nakamichi	1313
NEC	1250
Nexius	1390
Nikkai	1389
Nikkei	0744
Nikko	0609
Niro	1634
Norcent	1389
Nova	1389
NTDE Geniesom	0744
Omni	1508, 1772
Onkyo	1298, 1320, 1805
Optimus	1023, 0186, 0531, 0744, 0797
Orient Power	0744
Orion	0463
Palladium	0797, 1293, 1390
Panasonic	1308, 1518, 0367, 1288, 1309, 1316, 1548, 1633, 1763, 1764, 1779
Penney	0744
Philco	1390
Philips	1189, 1269, 0391, 1089, 1266, 1289, 1673
Phonotrend	0502
Pioneer	1023, 0150, 0186, 0244, 0531, 0630, 1384, 1459, 1935, 1986
PJ	1389
Polaroid	1508
Polk Audio	1289
Prima Electronic	0797
Proline	0797, 1390
ProVision	1389
Qisheng	1609, 1390
QONIX	1390

Wireless Link IR Code List	
Setup Codes For Audio - Receiver (R).....Continued	Receiver
Radionette	1293, 1634
RadioShack	0744
RCA	1023, 1609, 0531, 1154, 1390, 1459, 1511
Recco	0797
Redstar	1389
Revox	0186, 1089
Roadstar	0797, 1772
Saba	0531
Samsung	1295, 1304, 1500
Sansui	1189, 0609, 1089, 1764, 1772
Sanyo	0744, 1251, 1469, 1801
Schneider	0110, 0531, 0744, 1390
Scott	1389
SEG	1250
Sharp	0186, 0653, 1634
Sharper Image	0797
Sherwood	0491, 0502, 0653, 1077, 1423, 1653
Shinco	1390
Siemens	0609
Silsonic	0176
Silva Schneider	0797, 1390
Sony	1622, 2172, 1858, 1658, 1558
Soundwave	0609
Starlight	0797
Stereophonics	1023
Sumida	0744
Sunfire	1313
Sylvania	0797
TAG McLaren	1189
Targa	1293
TCM	0797
Teac	0463, 0609, 0744, 0797, 1390
Technics	1308, 1518, 1309, 1384, 1633, 1763

Wireless Link IR Code List		
Setup Codes For Audio - Receiver (R).....Continued		Receiver
Techwood	0609	
Telefunken	0531, 1389, 1390, 1772	
Tevion	1389	
Thomson	1154	
Thorens	1189	
Thorn	0744	
Tokai	1390	
Uher	0391, 0531	
United	1390, 1772	
Universum	1609, 0609, 0744, 0797, 1390	
Venturer	0797, 1390	
Victor	0074	
Watson	0797	
Wellfund	0744	
Welltech	0797	
Wharfedale	1390, 1772	
Xenius	1390	
XLogic	1772	
Yamaha	0176, 0186, 1276, 1331, 1376	
Zenith	0744, 0857, 1293	
Wireless Link IR Code List		
Setup Codes For Satellite Set Top Box (S)		Satellite
@sat	1300	
@Sky	1334	
Acoustic Solutions	1284	
ADB	0887, 1259	
Akai	0200	

Wireless Link IR Code List

Setup Codes For Satellite Set Top Box (S).....Continued

Satellite

Alba	1284
Allsat	0200
Allvision	1232, 1334
Amstrad	0847, 1175
Aonvision	2279
Apro	1672
Armstrong	0200
Arnion	1300
Asat	0200
ASCI	1334
AssCom	0853
Astratec	1743
Astro	0173, 1099, 1100
Atsat	1300
AtSky	1334
Audioline	1672
Aurora	0879, 1433
Austar	0879, 1259
Axil	1413, 1457, 1993
Axis	1111
Axitronic	1626
Balmet	1457
Bell ExpressVu	0775, 1170
Best Buy	1993
Big Sat	1457
Black Diamond	1284
Blaupunkt	0173
Boca	1232, 1366, 2026
Boston	1251
Brainwave	1672
British Sky Broadcasting	0847, 1175, 1662
BskyB	0847, 1175, 1662
BT	1296

Wireless Link IR Code List

Setup Codes For Satellite Set Top Box (S).....Continued

Satellite

Bush	1284, 1291, 1645, 1672, 1743
Canal Digital	0853
Canal Satellite	0853
Canal+	0853
Centrex	1457
Century	0856
CGV	1413, 1567
Chess	1334, 1626, 2026
CityCom	1176, 1232
Classic	1672
Clatronic	1413
Comag	1232, 1366, 1413, 2026
Comsat	1413
Coship	1457, 1672
Crossdigital	1109
Crown	1284
Cyfra+	1076
Cyrus	0200
D-box	0723, 1114
Daewoo	1111, 1296, 1743
DAK	1993
Dantax	1626
Dgtec	1242
Digiality	1334
Digifusion	1645, 1743
Digihome	1284
DigiLogic	1284
DigiQuest	1300, 1457
DigiSat	1232
Digisky	1457
DigitAll World	1227
Digiturk	1076
Dijam	1296

Wireless Link IR Code List

Setup Codes For Satellite Set Top Box (S).....Continued

Satellite

DirectV	1377, 0566, 1639, 1142, 0247, 0749, 1749, 0819, 1856, 1076, 1108, 1109, 1392, 1414, 1442, 1609
Dish Network System	1505, 1005, 0775, 1170, 1775
Dishpro	1505, 1005, 0775, 1775
DNT	0200
Dream Multimedia	1237
DSTV	0879, 1433
Durabrand	1284
DX Antenna	1530
Echostar	1505, 1005, 0775, 0853, 1170, 1323, 1409, 1775
Elap	1413, 1567
Elta	0200
eMTech	1214
Engel	1251, 1993
EuroLine	1251
Expressvu	0775, 1775
Ferguson	1291, 1743
Finlux	1626
Fly Com	1457
FMD	1413, 1457
Foxtel	0879, 1176, 1356
Free Wave Technology	1743
Fuba	0173, 1214, 1251
Galaxis	0853, 1111, 0879, 1557
GbSAT	1214
GE	0566
General Satellite	1176
Globo	1251, 1334, 1429, 1626, 2026
GOD Digital	0200
GOI	0775, 1775
Gold Box	0853
GoldMaster	1334

Wireless Link IR Code List

Setup Codes For Satellite Set Top Box (S).....Continued

Satellite

Goodmans	1284, 1291
Gradiente	0856, 0887
Grandin	1626
Grococ	1457
Grundig	0847, 0853, 0173, 0879, 1284, 1291, 1672
Hama	1567
Hanseatic	1099, 1100
Hauppauge	1672
HB	1214
Hills	1232
Hirschmann	1111, 0173, 1232
Hitachi	0819, 1250, 1284, 1518
Homecast	1214
Hornet	1300
HTS	0775, 1775
Hughes Network Systems	1142, 0749, 1749, 1442
Humax	1176, 1427, 1675, 1743, 1788, 1808
ID Digital	1176
ILLUSION sat	1557
Imperial	1195, 1197, 1334, 1429, 1672
Indovision	0856, 0887
Inno Hit	1626
Interstar	1214
Inves	1743, 1993
iotronic	1413
ISkyB	0887
ITT Nokia	0723
Jaeger	1334
JVC	0775, 1170, 1775, 1793, 1797
Kaon	1300
KaTelco	1111
Kathrein	0173, 0200, 1561, 1567
Kenwood	0853

Wireless Link IR Code List

Setup Codes For Satellite Set Top Box (S).....Continued

Satellite

Kreismeyer	0173
L&S Electronic	1334
Labgear	1296
LaSAT	0173
Leiko	1626
Lemon	1334
Lenox	1611
LG	1226, 1414
Listo	1626
Lodos	1284
Logik	1284
M vision	1557
Magnavox	0722
Manhattan	1300
Marantz	0200
Maspro	0173, 1530
Matsui	0173, 1284, 1626, 1743
Maximum	1334
Mediabox	0853
Mediacom	1206
MediaSat	0853
Medion	1232, 1334, 1626, 2026
Mega	0200
Metronic	1334, 1413
Metz	0173
MiCO	1993
Mitsubishi	0749
Morgan's	0200, 1232
Motorola	0856
Multichoice	0879, 1433, 1959, 1960
Myryad	0200
MySky	1356
Neom	1993

Wireless Link IR Code List

Setup Codes For Satellite Set Top Box (S).....Continued

Satellite

NEOTION	1334
Netgem	1322
Netsat	0887
Neuf TV	1322
Neuling	1232
Nikko	0723, 0200
Nokia	0853, 0723, 1023, 1223
Nordmende	1611
OctalTV	1505
Omni	1993
Onn	1284
Opentel	1232
Optex	1413, 1611, 1626
Optus	0879, 1356
Orbis	1232, 1334
Orbitech	1099, 1100, 1195, 1197
P/Sat	1232
Pace	0847, 0853, 0200, 0887, 1175, 0329, 1323, 1356
Pacific	1284
Packard Bell	1111
Palcom	1409
Panasat	0879, 1433
Panasonic	0247, 0701, 0847, 1304, 1404
Panda	0173
Pass	1567
peekTon	1457, 1993
Philips	1142, 0749, 1749, 0819, 0856, 1076, 0722, 0853, 0173, 0200, 1114, 0887, 0133, 1442, 1672, 1743
Pino	1334
Pioneer	0853, 0329, 1308
PMB	1611
Portland	1296

Wireless Link IR Code List

Setup Codes For Satellite Set Top Box (S).....Continued

Satellite

Preisner	1366
Premier	0723, 1429
Primacom	1111
Proline	1284
Proscan	0566
QNS	1404
Radiola	0200
RCA	0566, 0855, 0143, 1291, 1392
Rebox	1214
Regal	1251
RFT	0200
Roadstar	0853
Rollmaster	1413
Rowsonic	1567
SAB	1251, 1300
Sagem	0820, 1114
Samsung	1377, 1142, 1276, 1108, 1109, 0853, 1206, 1442, 1609
Sansui	1251
Sanyo	1182, 1626
Sat Control	1300
SAT+	1409
Satelco	1232
Satplus	1100
Schaub Lorenz	1214
Schneider	1206, 1251
Schwaiger	1111, 1334, 1457
Sedea Electronique	1206, 1626
Seeltech	1993
SEG	1251, 1626, 1993
Servimat	1611
ServiSat	1251
Sharp	1489

Wireless Link IR Code List

Setup Codes For Satellite Set Top Box (S).....Continued

Satellite

Sherwood	1409
Siemens	0173, 1334, 1429
SilverCrest	2026
SKY	0856, 1856, 0847, 0887, 1175, 1662
SKY Brazil	0856, 0887
SKY Italia	0853
Sky XL	1251
Sky+	1175
Skymaster	1334, 1409, 1567, 1611
Skymax	0200, 1413
Skyplus	1232, 1334, 2026
Skyvision	1334
SL	1672, 2026
SM Electronic	1409
Smart	1232, 1404, 1413
Sony	0853, 1639, 0847
Star	0887
Star Sat	1214
Starlite	0200
Stream System	1300
Strong	0853, 0820, 0879, 1284, 1300, 1409, 1626
Sunny	1300
Sunstech	1993
Supernova	0887
Supratech	1413
Systec	1334
TBoston	1251
TCL	2265
Teac	1227, 1251, 1322
Technical	1626
TechniSat	1099, 1100, 1195, 1197, 1322
Technomate	1610
Technosat	1206

Wireless Link IR Code List

Setup Codes For Satellite Set Top Box (S).....Continued

Satellite

Technosonic	1672
Technotrend	1429
Techwood	1284, 1626
TELE System	1251, 1409, 1611
Telestar	1099, 1100, 1195, 1197, 1251, 1334, 1610, 1626, 1672
Televés	1214, 1300, 1334
Televisa	0887
Telewire	1232
Tevion	1409, 1672, 1993
Thomson	0847, 0853, 0820, 1175, 1046, 1291, 1662
Tiny	1672
Tividi	1429
Tivo	1142, 1442
Tokai	0200
Tonna	1611
Topfield	1206, 1208
Toshiba	0749, 1749, 0790, 1284, 1285, 1501, 1516, 1530
TPS	0820
Trevi	1251
Triax	0853, 0200, 1227, 1251, 1291, 1296, 1413, 1611, 1626
TT-micro	1429
Twinner	1611
UEC	0879, 1356
UltimateTV	1392
Uniden	0722
Unisat	0200
United	1251
Universum	0173, 1099, 1251
Vaova	1993
Variosat	0173

Wireless Link IR Code List

Setup Codes For Satellite Set Top Box (S).....Continued

Satellite

Ventana	0200
Vestel	1251
ViewSat	1232
Viola Digital	1672
Vision	1626
VisionNet	1557
Visiosat	1413, 1457
Vitecom	1413
Viva	0856
Wavelength	1232, 1413
Wharfedale	1284
Wisi	0173, 1232
Worldsat	1214, 1251
Xsat	0847, 1214, 1323
Xtreme	1300
Yakumo	1413
Yamada	1993
Yes	0887
Zehnder	1232, 1251, 1334, 1413
Zenith	0856, 1856
Zeta Technology	0200

Wireless Link IR Code List

SAT/PVR Combination (S)

Satellite

@sat	1300
Amstrad	1175
Atsat	1300
Bell ExpressVu	0775, 1170

Wireless Link IR Code List		Satellite
SAT/PVR Combination (S).....Continued		
British Sky Broadcasting	1175	
BskyB	1175, 1662	
Bush	1645	
Digifusion	1645	
DigiQuest	1300	
Digiturk	1076	
DirectV	1377, 1142, 1076, 1392, 1442	
Dish Network System	1505, 0775	
Dishpro	1505, 0775	
Dream Multimedia	1237	
Echostar	1505, 0775, 1170	
eMTech	1214	
Expressvu	0775	
Foxtel	1356	
GbSAT	1214	
Hughes Network Systems	1142, 1442	
Humax	1176, 1427, 1675, 1788, 1808	
JVC	1170	
Kaon	1300	
Kathrein	1561	
Maximum	1334	
Mediacom	1206	
MySky	1356	
NEOTION	1334	
Nokia	1023	
Omni	1993	
Pace	1175, 1356	
Panasonic	1304	
Philips	1142, 1442	
RCA	1392	
Rebox	1214	
Samsung	1206, 1442, 1609	
Sat Control	1300	

Wireless Link IR Code List SAT/PVR Combination (S).....Continued		Satellite
Schneider	1206	
Sedea Electronique	1206	
Sharp	1489	
SKY	1175, 1662	
Skyplus	1334	
Stream System	1300	
Strong	1300	
Sunny	1300	
TechniSat	1195, 1197	
Technosat	1206	
Telestar	1195, 1197	
Thomson	1175, 1662	
Tivo	1142, 1442	
Topfield	1206	
Xtreme	1300	
Yamada	1993	
Wireless Link IR Code List Setup Codes For Video - VCR (V)		
		VCR
ABS	1972	
Accent	0072	
Accurian	0000	
Admiral	0048, 0209, 0479	
Adventura	0000	
Adyson	0072	
AEG	1593	
Aiko	0278	
Aim	0278, 0348, 0642	

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

Aiwa	0037, 0000, 0209, 0041, 0348, 0307, 0124, 0468, 0479, 0742, 1137
Akai	0037, 0240, 0000, 0041, 0348, 0642, 0315
Akiba	0072
Akura	0041, 0072
Alba	0081, 0000, 0209, 0072, 0278, 0348, 0315
Alienware	1972
Allegro	1137
Allorgan	0240
Allstar	0081
America Action	0278
American High	0035
Amoisonic	0479
Amstrad	0000, 0072, 0278
Anam	0162, 0037, 0240, 0278, 0226, 1037
Anam National	0162, 1562, 0226, 1162
Anitech	0072
Ansonic	0000
Aristona	0081
ASA	0037, 0081
Asha	0240
Asuka	0037, 0081, 0000, 0072, 0038
Audio Dynamics	0040
Audiolab	0081
Audiosonic	0278
Audiovox	0037, 0278
AVP	0000
Awa	0037, 0043, 0278, 0642, 0075
Baird	0000, 0104, 0041, 0278
Basic Line	0104, 0072, 0278, 0046
Beaumarck	0240
Beko	0104
Bell & Howell	0104

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

Bestar	0278
Black Diamond	0642
Black Panther	0278
Blaupunkt	0162, 0081, 0226
Blue Sky	0037, 0209, 0072, 0278, 0348, 0642, 0742, 1137
Bondstec	0072
BPL	0046
Brandt	0041
Brandt Electronique	0041
Brinkmann	0209, 0348
Broksonic	0184, 0121, 0209, 0002, 0348, 0479
Bush	0081, 0000, 0209, 0072, 0278, 0348, 0642, 0315, 0742
Calix	0037
Canon	0035
Carena	0081, 0209
Carrefour	0045
Carver	0081
Casio	0000
Cathay	0278
CCE	0072, 0278
Centrum	0593, 1593
CGE	0000, 0041
Changhong	0048, 0081
Cimline	0209, 0072
Cineral	0278
CineVision	1137
Citizen	0037, 0278
Clatronic	0000, 0072, 1593
Colt	0072
Condor	0278
Craig	0037, 0047, 0240, 0072

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

Crown	0037, 0072, 0278
Curtis Mathes	0060, 0035, 0162, 0041
Cybernex	0240
CyberPower	1972
Cyrus	0081
Daewoo	0045, 0104, 0209, 0278, 0642, 0046, 1137
Dansai	0072, 0278
Dantax	0742
Daytron	0278
DBX	0040, 0050
De Graaf	0048, 0081, 0042, 0104, 0046
Decca	0081, 0000, 0067, 0209, 0041
Deitron	0278
Dell	1972
Denko	0072
Denon	0042
Diamant	0037
Diamond	0348
Dick Smith Electronics	0642
Digitor	0642
Dimensia	2613
DirectTV	0739
Domland	0209
DSE	0000, 0642, 1593
Dual	0081, 0000, 0041, 0278, 0348
Dumont	0081, 0000, 0104
Durabrand	0039, 0038, 0642, 0593, 1593
Dynatech	0000
Elbe	0278, 0038
Elcotech	0072
Electrohome	0037, 0043
Electroponic	0037
Elin	0240

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

Elsay	0072
Elta	0072, 0278
Emerson	0035, 0037, 0184, 0240, 0045, 0000, 0121, 0043, 0209, 0072, 0002, 0278, 0348, 0479, 0593, 1593
ESA	1137
ESC	0240, 0278
EuroLine	1593
Ferguson	0000, 0041, 0278, 0348, 0742
Fidelity	0240, 0000, 0072, 0432
Finlandia	0037, 0048, 0081, 0000, 0042, 0104, 0043, 0226, 0046
Finlux	0081, 0000, 0042, 0104
Firstline	0037, 0045, 0042, 0043, 0209, 0072, 0278, 0348, 1137
Fisher	0047, 0104, 0046
Flint	0209, 0348
Frontech	0072
Fuji	0035
Fujitsu	0045, 0000
Fujitsu General	0037
Fujitsu Siemens	1972
Funai	0000, 0593, 1593
Galaxi	0000
Galaxis	0278
Garrard	0000
Gateway	1972
GE	0060, 0035, 0048, 0240, 0226, 2613
GEC	0081
General	0045
General Technic	0348
Genexxa	0104
GFM	1593
Go Video	0240, 0432, 0526, 0614, 1137

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

GoldHand	0072
GoldStar	0037, 0000, 0209, 0038, 0226, 0225, 1137
Goodmans	0037, 0081, 0240, 0000, 0209, 0072, 0278, 0348, 0642, 0742
GPX	0037
Gradiente	0000, 1137
Graetz	0240, 0104, 0041
Granada	0037, 0048, 0081, 0240, 0000, 0042, 0104, 0226, 0046
Grandin	0037, 0000, 0209, 0072, 0278, 0742
Grundig	0081, 0072, 0348, 0226, 0742
Haaz	0348
Hanseatic	0037, 0081, 0209, 0038
Haojie	0240
Harley Davidson	0000
Harman/Kardon	0081, 0038, 0075
Harwood	0072
HCM	0072
Headquarter	0046
Hewlett Packard	1972
HI-Q	0047
Hinari	0240, 0209, 0041, 0072, 0278
Hisawa	0209
Hischito	0045
Hitachi	0037, 0081, 0240, 0000, 0042, 0041, 0046, 0089, 0593, 1037, 2613
Hoehner	0278, 0642
Hornyphon	0081
Howard Computers	1972
HP	1972
Hughes Network Systems	0042, 0739
Humax	0739, 1988
Hush	1972
Hypson	0037, 0000, 0209, 0072, 0278

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

iBUYPOWER	1972
Imperial	0000
Ingersol	0240, 0209
Inno Hit	0072
Instant Replay	0035, 0226
Interbuy	0037, 0072
Interfunk	0081, 0104
Internal	0278
International	0037, 0278, 0642
Intervision	0037, 0000, 0209, 0278, 0348
Irradio	0037, 0081, 0072, 1137
ITT	0240, 0104, 0041, 0046
ITV	0037, 0278
JBL	0278
Jensen	0041
JMB	0209, 0348, 0742
Joyce	0000
JVC	0081, 0045, 0067, 0041, 1162
Kaisui	0072
Kambrook	0037
Karcher	0081, 0278, 0642
KEC	0037, 0278
Kendo	0037, 0209, 0072, 0278, 0348, 0642, 0315
Kenwood	0067, 0041, 0038, 0046
KIC	0000
Kimari	0047
Kioto	0348
KLH	0072
Kneissel	0037, 0209, 0278, 0348
Kodak	0035, 0037
Kolin	0043, 0041
Kolster	0209
Korpel	0072

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

Kuba	0047
Kuba Electronic	0047
Kyoto	0072
Lenco	0278
Leyco	0072
LG	0037, 0045, 0000, 0042, 0209, 0278, 0038, 0040, 0225, 1037, 1137, 2010
Lifetec	0209, 0348
Linksys	1972
Lloyd's	0000
Loewe	1062, 0162, 0037, 0081, 1562, 1162, 1262
Logik	0240, 0209, 0072
Lumatron	0593, 1137
Lunatron	1137
Lux May	0072
Luxor	0048, 0047, 0104, 0043, 0072, 0315, 0046
LXI	0037
M Electronic	0037, 0000, 0038
Magnasonic	0278, 0593
Magnavox	0035, 0039, 0081, 0000, 0149, 0642, 0563, 0593, 1593
Magnin	0240
Magnum	0642
Manesth	0081, 0045, 0209, 0072
Marantz	0035, 0081, 0209, 0038
Mark	0000, 0278
Marta	0037
Mascom	0642
Mastec	0642
Master's	0278
Matsui	0037, 0240, 0209, 0278, 0348, 0742
Matsushita	0035, 0162, 0226, 1162
Media Center PC	1972

Wireless Link IR Code List		VCR
Setup Codes For Video - VCR (V).....Continued		
Mediator	0081	
Medion	0209, 0348, 0642	
MEI	0035	
Memorex	0035, 0162, 0037, 0048, 0039, 0047, 0240, 0000, 0104, 0209, 0348, 0307, 0046, 0479, 1037, 1048, 1162, 1262	
Memphis	0072	
Metronic	0081	
Metz	1062, 0162, 0037, 0081, 1562, 0226, 0837, 1162, 1262	
MGA	0240, 0043	
MGN Technology	0240	
Micormay	0348	
Micromaxx	0209	
Microsoft	1972	
Migros	0000	
Mind	1972	
Minolta	0042	
Mitsubishi	0048, 0081, 0000, 0067, 0043, 0041, 0642, 0075, 0173, 0214, 0443, 1631	
Motorola	0035, 0048	
MTC	0240, 0000	
Multitec	0037	
Multitech	0000, 0072	
Murphy	0000	
Myryad	0081	
NAD	0104	
Naiko	0348, 0642	
NAP	0039	
National	0226	
NEC	0035, 0037, 0048, 0104, 0067, 0041, 0278, 0038, 0040, 0050, 1137	
Neckermann	0081, 0041	
Nesco	0000, 0072	

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

Neufunk	0209, 1137
Newave	0037
Nikkai	0072, 0278
Nikko	0037
Niveus Media	1972
Noblex	0240
Nokia	0048, 0081, 0240, 0042, 0104, 0041, 0278, 0315, 0046
Nordmende	0067, 0041, 0642
Northgate	1972
Nu-Tec	0209
Oceanic	0048, 0081, 0000, 0104, 0041, 0046
Okano	0209, 0072, 0278, 0348, 0315
Olympus	0035, 0226
Onimax	0642
Optimus	1062, 0162, 0037, 0048, 0104, 0432, 0593, 1048, 1162, 1262
Orbit	0072
Orion	0184, 0121, 0209, 0002, 0348, 0479, 0742
Orson	0000
Osaki	0037, 0000, 0072
Osume	0072
Otake	0209
Otto Versand	0081
Pacific	0000, 0348, 0642, 0742
Packard Bell	1972
Palladium	0037, 0209, 0041, 0072, 0348
Palsonic	0000, 0072, 0642
Panasonic	1062, 0035, 0162, 1562, 0226, 0225, 0614, 0616, 0837, 1162, 1262
Pathe Cinema	0043
Pathe Marconi	0041
Penney	0035, 0037, 0240, 0042, 0038, 0040
Pentax	0042

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

Perdio	0000, 0209
Philco	0035, 0000, 0209, 0072, 0038, 0226, 0479
Philips	0035, 0081, 0000, 0226, 0563, 0593, 0618, 0739, 1081, 1181
Phoenix	0278
Phonola	0081
Pilot	0037
Pioneer	0162, 0081, 0042, 0067
Polk Audio	0081
Portland	0278
Presidian	1593
Prinz	0000
Profitronic	0081, 0240
Proline	0000, 0278, 0642
Proscan	0060
Proscopro	0278
Prosonic	0209, 0278
Protec	0072
Protech	0081, 0072
ProVision	0278
Pulsar	0039
Pye	0081, 0000
Qisheng	0060
Quarter	0046
Quartz	0046
Quasar	0035, 0162, 0278, 1162
Quelle	0081
Radialva	0037, 0048, 0081, 0072
Radiola	0081
Radionette	0037, 1137
RadioShack	0037, 0000, 1037
Radix	0037
Randex	0037

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

Rank	0041
Rank Arena	0041
RCA	0060, 0035, 0048, 0240, 0000, 0042, 0149, 0226, 0880, 2613
Realistic	0035, 0037, 0048, 0047, 0000, 0104, 0046
Reoc	0348
ReplayTV	0614, 0616
Rex	0041
RFT	0072
Ricavision	1972
Rio	1137
Roadstar	0037, 0081, 0240, 0072, 0278, 0742
Royal	0072
Runco	0039
Saba	0041, 0278
Saisho	0209, 0348
Salora	0104, 0043, 0046, 0075, 0443
Sampo	0037, 0048
Samsung	0240, 0045, 0432, 0739, 0742, 1014
Sanky	0048, 0039
Sansei	0048
Sansui	0000, 0067, 0209, 0041, 0072, 0348, 0479
Sanyo	0048, 0047, 0240, 0104, 0067, 0348, 0046, 0159, 1137
Saville	0240, 0278
SBR	0081
ScanSonic	0240
Schaub Lorenz	0000, 0104, 0041, 0348, 0315
Schneider	0037, 0081, 0240, 0000, 0042, 0072, 0278, 0348, 0642, 1137
Scott	0184, 0045, 0121, 0043, 0593
Sears	0035, 0037, 0047, 0000, 0042, 0104, 0046
Seaway	0278
SEG	0081, 0240, 0072, 0278, 0642, 0593

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

SEI	0081
Sei-Sinudyne	0081
Seleco	0037, 0041
Semivox	0045, 0209
Semp	0045
Sentra	0072
Setron	0072
Sharp	0037, 0048, 0209, 0848, 1048, 1137
Shinco	0000
Shintom	0104, 0072
Shivaki	0037
Shogun	0240
Siemens	0037, 0081, 0104, 0046
Siera	0081
Silva	0037
Silva Schneider	1137
Silver	0278
SilverCrest	0642
Singer	0045, 0072, 0348
Sinudyne	0081, 0209
Smaragd	0348
Sonic Blue	0614, 0616, 1137
Sonneclair	0072
Sonolor	0048, 0046
Sontec	0037, 0278
Sonwa	0642
Sony	2184, 1232, 1546, 0000, 0035, 1972, 2181, 2182, 2183
Soundwave	0037, 0209, 0348
Ssangyong	0072
Stack 9	1972
Standard	0278
Stern	0278

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

STS	0042
Sunkai	0209, 0278, 0348
Sunstar	0000
Suntronic	0000
Sunwood	0072
Supra	0037, 0278, 0348
Sylvania	0035, 0081, 0000, 0043, 0593, 1593
Symphonic	0000, 0593, 1593
Systemax	1972
T+A	0162
Tagar Systems	1972
Taisho	0209
Tandberg	0278
Tandy	0000, 0104
Tashiko	0037, 0048, 0081, 0240, 0000
Tatung	0048, 0081, 0045, 0000, 0067, 0043, 0209, 0041, 0348
Tchibo	0348
TCM	0348
Teac	0037, 0000, 0041, 0072, 0278, 0307, 0642, 0526, 0593, 1593
Tec	0072
Tech Line	0072
Technics	0035, 0162, 0081, 0226, 1162
TechniSat	0348
Teco	0035, 0037, 0048, 0041, 0038, 0040
Tedalex	0037, 0209, 0348, 0642
Teknika	0035, 0037, 0000
Teleavia	0041
Telefunken	0209, 0041, 0278, 0642, 0593
Telerent	0226
Telestar	0037
Teletch	0000, 0072, 0278

Wireless Link IR Code List

Setup Codes For Video - VCR (V).....Continued

VCR

Tenosal	0072
Tensai	0037, 0000, 0072, 0278
Tevion	0209, 0348, 0642
Texet	0278
Thomas	0000
Thomson	0060, 0067, 0041, 0278
Thorn	0037, 0104, 0041
Tivo	0618, 0739
TMK	0240
Tokai	0037, 0104, 0041, 0072
Topline	0348
Toshiba	0081, 0045, 0042, 0067, 0043, 0209, 0041, 0432, 0742, 1008, 1972, 1988
Totevision	0037, 0240
Touch	1972
Towada	0072
Toyoda	0278
Tradex	0081
Triad	0278
Uher	0240
Ultravox	0278
Unitech	0240
United	0348, 0742, 1593
Universum	0037, 0081, 0240, 0000, 0104, 0209, 0348, 1137
Vector	0045
Vector Research	0038, 0040
VIA Technologies	1972
Victor	0067, 0041
Video Concepts	0045, 0040
Video Technic	0000
Video Track	0443
Videomagic	0037

Wireless Link IR Code List		VCR
Setup Codes For Video - VCR (V).....Continued		
Videasonic	0240	
Viewsonic	1972	
Villain	0000	
Voodoo	1972	
Wards	0060, 0035, 0048, 0039, 0047, 0081, 0240, 0045, 0000, 0042, 0072, 0038, 0149, 0046	
Watson	0081, 0642	
Weltblick	0037	
Wharfedale	0642, 0593	
White Westinghouse	0209, 0072, 0278	
World	0348	
XR-1000	0035, 0000, 0072	
Yamaha	0041, 0038	
Yamishi	0072, 0278	
Yokan	0072	
Yoko	0037, 0240, 0072	
Yoshita	0072	
Zenith	0039, 0000, 0209, 0479, 1137, 1139	
ZT Group	1972	
ZX	0209, 0348	

Wireless Link IR Code List		VCR
DVD/VCR Combination (V)		
Accurian	0000	
AEG	1593	
Akai	0000	
Allegro	1137	
Centrum	1593	

Wireless Link IR Code List

DVD/VCR Combination (V).....Continued

VCR

CineVision	1137
Clatronic	1593
Daewoo	1137
DSE	0000, 1593
Durabrand	1593
Emerson	0000, 1593
EuroLine	1593
Firstline	1137
Funai	0000, 1593
GFM	1593
Go Video	1137
GoldStar	1137
Hitachi	0000
Irradio	1137
LG	1137
Lunatron	1137
Magnavox	0000, 1593
Mitsubishi	1631
NEC	1137
Panasonic	0162, 1562
Philips	0081, 0593
Presidian	1593
Radionette	1137
RCA	0060
Rio	1137
Sanyo	0104
Schneider	1137
Sharp	0048, 0848, 1137
Silva Schneider	1137
Sylvania	0000, 0593, 1593
Symphonic	0000, 1593
Teac	1593
Toshiba	0045

Wireless Link IR Code List

DVD/VCR Combination (V).....Continued

VCR

United	1593
Universum	1137
Zenith	1137

Wireless Link IR Code List

PVR (V)

VCR

ABS	1972
Alienware	1972
CyberPower	1972
Dell	1972
DirectTV	0739
Gateway	1972
Go Video	0614
Hewlett Packard	1972
Howard Computers	1972
HP	1972
Hughes Network Systems	0739
Humax	0739, 1988
Hush	1972
iBUYPOWER	1972
LG	2010
Linksys	1972
Media Center PC	1972
Microsoft	1972
Mind	1972
Niveus Media	1972
Northgate	1972
Panasonic	0614, 0616

Wireless Link IR Code List

PVR (V).....Continued

VCR

Philips	0618, 0739
RCA	0880
ReplayTV	0614, 0616
Samsung	0739
Sonic Blue	0614, 0616
Sony	1972, 2181, 2182, 2183
Stack 9	1972
Systemax	1972
Tagar Systems	1972
Tivo	0618, 0739
Toshiba	1008, 1972, 1988
Touch	1972
Viewsonic	1972
Voodoo	1972
ZT Group	1972

Wireless Link IR Code List

HDD/DVD Combination (V)

VCR

Emerson	0000
Funai	0593
Humax	1988
RCA	0880
Sylvania	0000
Toshiba	1008, 1988

Wireless Link IR Code List

SAT/PVR Combination (V)

VCR

DirectTV	0739
Hughes Network Systems	0739
Philips	0739
Samsung	0739
Tivo	0739

Wireless Link IR Code List

Setup Codes For Video - DVD (Y)

DVD

3D LAB	0539
A-Trend	0714
Accurian	0675, 1416
Acoustic Solutions	0730, 0713, 1228
AEG	0675, 0788, 1233
AFK	1051, 1152
Aim	0672, 0778, 0833
Airis	0672, 0826, 1005, 1224, 1321
Aiwa	0533, 0641
Akai	0695, 0675, 0705, 0779, 0788, 0898, 1115, 1233
AKI	1005
Akira	1321
Akura	0898, 1051, 1140, 1233
Alba	0672, 0539, 0695, 0730, 0713, 0783, 1140, 1530
Alize	1151
Allegro	0869
Altacom	1224
Amitech	0784, 0850

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

Amoi	0852
Amphion Media Works	0872
Amstrad	0713, 1151
AMW	0872
Ansonic	0831, 0759
Apex Digital	0672, 1004, 1020, 1056, 1061
Arena	1115
Aristona	0539, 0646
Arrgo	1023
Asono	1224
Atacom	1224
Audix	0713
Autovox	0713
Auvio	0843
Awa	0730, 0872
Axion	0730
Basic Line	0713
Baze	0898
BBK	1224, 2168
Beep	1163
Bellagio	1004
Bellwood	0826
Black Diamond	0713, 0833
Blu:sens	1233, 1321
Blue Nova International	1321
Blue Parade	0571
Blue Sky	0672, 0651, 0695, 0713, 0778, 0843, 1423
Boghe	1004
Boman	0783, 0898, 1005
Brainwave	1115
Brandt	0503, 0651, 0551
Broksonic	0695, 0868
Byd:sign	0872

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

Bush	0672, 0730, 0831, 0713, 0733, 0778, 0833, 1051, 1128, 1140, 1483
C-Tech	1152
California Audio Labs	0490
Cambridge Audio	0751
Campomatic Digital	1051
Cat	0789, 1421
CCE	0730
Celestial	1020
cello	1730
Centrex	0672, 1004
Centrum	0675, 0713, 0779, 0789, 1005, 1227
CGV	0733, 0751, 1115
Changhong	0627, 1061
Cinea	0831, 0841
Cineral	0730
Cinetec	0713, 0872
CineVision	0833, 0869, 1483
Citizen	0695, 1277
Classic	0730, 1730
Clatronic	0672, 0675, 0788, 1233
Clayton	0713
Coby	0730, 0778, 0852, 1321
Codex	1233
Commax	1321
Compacts	0826
Conia	0672, 0852, 1321
Contel	0788
Continental Edison	0831, 0872
Craig	0831
Crown	0713, 1115
Crypto	1228
Curtis Mathes	1087

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

Cybercom	0831
CyberHome	0714, 0816, 1023, 1024, 1129, 1502
Cytron	0651, 0705, 1347, 1423
D-Vision	1115
Daenyx	0872
Daewoo	0784, 0705, 0714, 0833, 0869, 0872, 1169, 1172, 1483
Dalton	1036
Dansai	0783, 1115
Dantax	0539, 0713
Daytek	0872, 1005
Dayton	0872
DCE	0831
DEC	0778
Decca	1115
Denon	0490, 0634, 1634, 2258
Denver	0672, 0778, 0788, 0898, 1056, 1321
Desay	0843
Dgtec	0672
Diamond	0651, 0768, 0751, 0778
Dick Smith Electronics	0833, 1152, 1483, 1730
Digihome	0713
DigiLogic	0713
Digitor	0651, 0833, 1005, 1423
Digitrex	0672, 1004, 1056
Digix Media	0826
DiK	0831
Dinamic	0788
Disney	0831, 0675, 1270
DiViDo	0705
DK Digital	0831
DMTech	0783
Dragon	0831

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

DreamX	1151
DSE	0675, 0833, 1152, 1423, 1483, 1730
Dual	0651, 0730, 0831, 0713, 0779, 0783, 1023, 1530
Durabrand	0831, 0675, 0713, 1023, 1502, 2164
DVD2000	0521
DVX	0768
E:max	1233, 1321
EagleTec	0714
eBench	1152
ECC	0730
Eclipse	0751
Elfunk	0713, 0850
Elite	1152
Ellion	0850, 1421
Elta	0672, 0784, 0788, 0850, 1051, 1115, 1151, 1233
Eltax	1233, 1321
Emerson	0591, 0675, 0705, 0821, 1268
Enterprise	0591
Enzer	0784, 1228
ESA	0821, 1268
EuroLine	0675, 0788, 1115, 1233
Fenner	0651
Ferguson	0651, 0695, 0713, 0898, 1730
Finlux	0672, 0591, 0741, 0751, 0783
Fintec	1169, 1530
Firstline	0713, 0843, 0869, 1530
Funai	0695, 0675, 1268, 1334
GE	0522, 0815
Germatic	1051
GFM	0675, 1268
Global Link	1224

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

Global Solutions	0768
Global Sphere	1152
Go Video	0744, 0741, 0715, 0783, 0833, 0869, 1044, 1075, 1304, 1483, 1730
GoldStar	0591, 0741
Goodmans	0651, 0730, 0713, 0783, 0833, 1004, 1140, 1152, 1423, 1530, 1730
GP Audio	1140
GPX	0741
Gradiente	0490, 0651
Gran Prix	0831, 0898
Grandin	0713, 1233
Grundig	0539, 0651, 0551, 0695, 0705, 0713, 0775, 1004, 1036, 1128, 1730
Grunkel	0831
GVG	1169
H & B	0713, 0841, 0850, 1233, 1421
Haaz	0751, 1152
Haier	0843
Hanseatic	0741, 0783
Harman/Kardon	0702
HCM	0788
HDT	0705
HE	0730, 1163
Helios	2080, 2192
Hello Kitty	0831
Henss	0713
Highlander	1224
HiMAX	0843
Hitachi	0573, 0664, 0695, 0713, 1247, 1664, 1748
Hiteker	0672
Hoehner	0651, 0831, 0713, 0826, 1004, 1224, 1530
Home Electronics	0730

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

Home Tech Industries	1224
HofMedia	1152
Humax	0646, 1588
HYD	1233
Hyundai	0768, 0783, 0826, 0850, 1061, 1228
iLo	1472
Ingelen	0788
Ingersol	1023
Initial	1472
Inno Hit	0713
Insignia	1268
Integra	0571, 0627, 1634, 1769
Irradio	0869, 1115, 1224, 1233
IRT	0783
ISP	0695
Jamo	1036
JBL	0702
JDB	0730
JMB	0695
JNC	0672
JSI	1423
JVC	0503, 0539, 0558, 0623, 0867, 1164, 1275, 1550, 1590, 1591, 1592, 1594, 1597, 1602
jWin	1051
Kansas Technologies	1233, 1530
Karcher	0783
Kendo	0672, 0831, 0713, 1483
Kennex	0713, 0898
Kenwood	0490, 0534
King D'Home	0833
Kiss	0841
KLH	0815, 1020
Koss	0651, 1423

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

Kreisen	1421
KXD	1321
Landel	0826
Lawson	0768
Leiker	0872
Lenco	0651, 0713, 0778
Lenoir	1228
Lenox	1005
Lexia	0768
LG	0591, 0741, 0869, 1600, 2135
Lifetec	0651, 0831, 1347
Limit	0768
LifeOn	1058, 1416
Lodos	0713
Loewe	0539, 0741, 0511
Logik	0713
Logix	0705, 0783
Lumatron	0741, 0695, 0705, 0713, 0833, 1115, 1321
Lunatron	0741
Luxman	0573
Luxor	0713, 1004, 1730
Magnasonic	0651
Magnavox	0503, 0539, 0646, 0675, 0713, 0733, 0821, 1140, 1268, 1354, 1472, 1506
Manhattan	0705, 0713
Marantz	0539
Mark	0713
Matsui	0672, 0651, 0695, 0713, 1004, 1730
Maxdorf	0788
Maxent	1347
Maxim	0713, 0872
MBO	0730, 1730
MDS	0713, 0778

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

Mediencom	0751
Medion	0651, 0630, 0741, 0831, 0783, 1270, 1347, 1423
Memorex	0695, 0831, 1270, 2213
Metz	0525, 0571, 0713
MiCO	0751, 1223
Micromaxx	0695
Micromedia	0503, 0539
Micromega	0539, 1005
Microsoft	0522, 2083
Microstar	0831
Minato	0752
Minax	0713
Minerva	0705
Minoka	1115
Mintek	1472
Mirror	0752
Mitsubishi	1521, 0521, 0713, 1629
MPX	0843
Mustek	0730, 1730
Mx Onda	0651, 0751, 1223
Mystral	0831
NAD	0741
Naiko	1004
NEC	0741, 0785, 0869, 1602
Nevir	0672, 0831
Next Base	0826
NFREN	0826
Nintaus	1051
Norcent	0872
Nordmende	0831
Noriko	0752
Nowa	0843

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

Nu-Tec	1228
Okano	0752
Olidata	0672
Omni	0778, 0833
Onkyo	0503, 0627, 0792, 1769
Oppo	0575, 1224
Optim	0843
Optimus	0525
Orbit	0872
Orion	0695, 0713, 1128, 1233
Oritron	0651
Ormond	0713
Otic	0826
Pacific	0831, 0768, 0713, 0759
Packard Bell	0831, 1321
Palladium	0695, 0713, 0779
Palsonic	0672, 0833, 0852, 1056, 1321
Panasonic	0503, 0490, 0703, 1632, 1641, 1762
Panda	0789
Paramount Pictures	0779
peeKton	0898, 1224
Philco	0675, 0733, 0788
Philips	0503, 0539, 0646, 0675, 1260, 1267, 1340, 1354, 1506, 2056, 2084, 2093
PianoDisc	1024
Pioneer	0525, 0571, 0142, 0631
Plu2	0850
Polaroid	1020, 1061, 2130
Polk Audio	0539
Powerpoint	0872, 1005
Presidian	0675
Prima	1228
Prinz	0831

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

Prism	0831, 0705
ProCaster	1004
Proceed	0672
Proline	0672, 0651, 0710, 0833, 1004, 1483
Proscan	0522
Proson	0713
Prosonic	0752, 1169
ProVision	0730, 0778, 1163, 1321
Pye	0539, 0646
QONIX	1051
Qwestar	0651
Radionette	0741, 0869
Radiotone	0713
RCA	0522, 0571, 0822, 1769
REC	0490
Redstar	0759, 0763, 0788, 0898
Relisys	1347
Reoc	0768, 0752
Revoy	0841
Richmond	1233
Rio	0869
Roadstar	0672, 0730, 0713, 0833, 0898, 1051, 1227
Rocksonic	0789
Ronin	0710, 0872
Rotel	0558, 0623
Rowa	0759, 0872, 1004
Rowsonic	0789
Saba	0651, 0551
Saivod	0831, 0759
Salora	0741
Sampo	0752, 1321, 1347
Samsung	0490, 0573, 0744, 0199, 0820, 1044, 1075, 1470, 1599, 1635, 1748, 2069

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

Sansui	0784, 0695, 0768, 0751, 0763, 1051, 1228
Santosh	1115
Sanyo	0695, 0713, 0873, 1228
Scan	0705, 0850
ScanMagic	0730, 1730
Schaub Lorenz	0788, 1115, 1151
Schneider	0539, 0646, 0651, 0831, 0705, 0713, 0779, 0783, 0788, 0869, 1227
Schoentech	0713
Schwaiger	0752
Scientific Labs	0768
Scott	0672, 0651, 1005, 1036, 1233, 1423
Seeltech	1224
SEG	0713, 0763, 0872, 1483, 1530
Semp	0503
Shanghai	0672
Sharp	0630, 0675, 0713, 0752, 0869, 1256, 1556, 1642, 2250
Sherwood	0741
Shinco	1472
Shinsonic	0533
Sigmatek	1005, 1224
Siltex	1224
Silva	0788, 0898
Silva Schneider	0741, 0831, 0869, 0898
SilverCrest	1152
Singer	0768, 0751
Sistemas	0672
Skantic	0539, 0713
Skymaster	0730, 0768
Skyworth	0898, 2148
Sliding	1115
Slim Art	0784

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

SM Electronic	0730, 0768, 1152
Smart	0705, 0713
Sonashi	0831
Sonic Blue	0783, 0869
Sony	1033, 0864, 1633, 1070, 1069, 0573, 0630, 1516, 2178, 2180, 0533
Sound Color	1233
Soundmaster	0768
Soundmax	0768
Soundwave	0713, 0783
Spectra	0872
Standard	0651, 0831, 0768, 0788, 0898
Star Clusters	1152, 1227
Starlogic	1005
Starmedia	1005, 1224
Strato	1152
Strong	0713
Sunkai	0850
Sunstech	0831
Sunwood	0788, 0898
Superscan	0821
Supervision	0768, 1152
SVA	0672, 0752
Sylvania	0630, 0675, 0821, 1268, 2194
Symphonic	0675, 0821, 1268
Synn	0768
Syscom	0826
Tandberg	0713
Tangent	1321
Targa	1227
Tchibo	0741
TCL	1260
TCM	0741

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

Teac	0571, 0741, 0768, 0675, 0705, 0759, 0833, 1227, 1483
Tec	0898
Technics	0490, 0703
Technika	0831, 1115
Technisson	1115
Technosonic	0730, 1051, 1115
Techwood	0713, 1530
Tedelex	0768, 1004, 1228
Telefunken	0551, 0789, 0833, 1483
Teletch	0768, 0713
Tensai	0651
Tevion	0651, 0768, 0833, 0898, 1036, 1227, 1347, 1421, 1483, 1730
Theta Digital	0571
Thomson	0522, 0551
Tivo	1503, 1588
Tokai	0784, 0788, 0898, 1233
Tom-Tec	0789, 0833
Top Suxess	1224
Toshiba	0503, 0695, 1154, 1503, 1510, 1588, 1595, 1608, 1639, 1769, 1854
TProgress	0752
TRANS-continent	0831, 0826, 0833, 0872, 1233, 1321
Trasonic	0730
Tredex	0843
Trevi	0831
TSM	1224
TVE	0713
TYT	0705
Umax	1151
United	0695, 0730, 0675, 0713, 0788, 0826, 1115, 1152, 1228, 1233
Universum	0591, 0741, 0713, 0779, 0869, 1227, 1530

Wireless Link IR Code List

Setup Codes For Video - DVD (Y).....Continued

DVD

Uptek	0763
Urban Concepts	0503
Venturer	1769
Vestel	0713, 1530
Victor	1597
Vieta	0705
Viewmaster	1224
Voxson	0730, 0831
Vtrek	1228
Waitec	0730, 1151, 1224, 1233
Waltham	0713, 1530
Welkin	0831
Wellington	0713
Weltstar	0713
Wharfedale	0713, 0751, 0752, 1115
Wilson	0831, 1233
Windsor	0713
Windy Sam	0573
WIZE	1115
Woxter	1005, 1151, 1224
Wyse	1652
Xbox	0522, 2083
XLogic	0768, 1152, 1228
XMS	0788
Yakumo	1004, 1056
Yamada	0872, 1004, 1056, 1151, 1416
Yamaha	0490, 0539, 0646, 0545, 0817
Yamakawa	0710, 0872
Yukai	0730, 1730
Zenith	0503, 0591, 0741, 0869
Zeus	0784

Wireless Link IR Code List

DVD Changer (Y)

DVD

Denon	0634, 1634
GE	0815
Harman/Kardon	0702
JBL	0702
JVC	0623
Onkyo	0627
Panasonic	0490
Sharp	0630
Sony	1033, 1069, 1633
Sylvania	0675
Toshiba	0503, 1154
Yamaha	0545, 0817
Zenith	0741

Wireless Link IR Code List

DVD-R (Y)

DVD

Accurian	0675, 1416
Airis	1321
Akira	1321
Alba	1530
Apex Digital	1056
Aristona	0646
Cat	1421
cello	1730
Centrum	1227
Classic	1730
Commax	1321
Conia	1321

Wireless Link IR Code List

DVD-R (Y).....Continued

DVD

CyberHome	1129, 1502
Cytron	1347
Denon	0490
Denver	1056
Dick Smith Electronics	1730
Digitrex	1056
DSE	1730
Dual	1530
Durabrand	1502
E:max	1321
Ellion	1421
Eltax	1321
Emerson	0675
Ferguson	1730
Fintec	1530
Firstline	1530
Funai	0675, 1334
Go Video	0741, 1304, 1730
Goodmans	1530, 1730
GPX	0741
Grundig	1730
H & B	1421
Hitachi	1664, 1748
Hoehner	1530
Humax	0646, 1588
JVC	1164, 1275, 1597
Kansas Technologies	1530
Kreisen	1421
KXD	1321
LG	0741, 2135
Lifetec	1347
LiteOn	1416
Loewe	0741

Wireless Link IR Code List

DVD-R (Y).....Continued

DVD

Lumatron	1321
Luxor	1730
Magnavox	0646, 0675, 1506
Matsui	1730
Maxent	1347
MBO	1730
Medion	1347
MiCO	0751
Mitsubishi	1629
Mustek	1730
Packard Bell	1321
Palsonic	1056, 1321
Panasonic	0490
Philips	0646, 1340, 1506, 2093
Pioneer	0631
Polaroid	2130
ProVision	1321
Pye	0646
RCA	0522
Relisys	1347
Roadstar	1227
Sampo	1347
Samsung	0490, 1470, 1635, 1748
ScanMagic	1730
Schneider	0646, 1227
SEG	1530
Sharp	0630, 0675, 1556, 1642
Sony	1033, 1069, 1070
Star Clusters	1227
Sylvania	0675
Tangent	1321
Targa	1227
Teac	1227

Wireless Link IR Code List

DVD-R (Y).....Continued

DVD

Techwood	1530
Tevion	1227, 1347, 1421, 1730
Thomson	0551
Toshiba	1510, 1588, 1639
Universum	1227, 1530
Vestel	1530
Victor	1597
Waltham	1530
Yakumo	1056
Yamada	1056, 1416
Yamaha	0646
Yukai	1730
Zenith	0741

Wireless Link IR Code List

DVD/VCR Combination (Y)

DVD

Accurian	0675
AEG	0675
Aim	0833
Akai	0675
Allegro	0869
Apex Digital	1061
Black Diamond	0833
Broksonic	0695
Bush	0833, 1483
Centrum	0675
CineVision	0833, 0869, 1483
Clatronic	0675

Wireless Link IR Code List		DVD
DVD/VCR Combination (Y).....Continued		
Daewoo	0833, 0869, 1483	
Dick Smith Electronics	0833, 1483	
Digitor	0833	
DSE	0675, 0833, 1483	
Durabrand	0675	
Emerson	0675	
EuroLine	0675	
Firstline	0869	
Funai	0695, 0675	
GFM	0675	
Go Video	0744, 0741, 0715, 0833, 0869, 1044, 1075, 1483	
GoldStar	0741	
Goodmans	0833	
Hitachi	0664	
Hyundai	1061	
Irradio	0869	
JVC	0867, 1164, 1550, 1602	
Kendo	1483	
King D'Home	0833	
LG	0741, 0869	
Lumatron	0741, 0695, 0833	
Lunatron	0741	
Magnavox	0675	
Memorex	0695	
Micromaxx	0695	
Mitsubishi	1629	
NEC	0869, 1602	
Omni	0833	
Orion	0695	
Palsonic	0833	
Panasonic	0490, 1762	
Philips	0539, 0646, 0675, 1267	

Wireless Link IR Code List

DVD/VCR Combination (Y).....Continued

DVD

Pioneer	0631
Polaroid	1061
Presidian	0675
Proline	0833, 1483
Radionette	0869
RCA	0522, 0822
Roadstar	0833
Samsung	0744, 0820, 1044, 1075
Sansui	0695
Sanyo	0695, 0873
Schneider	0869
SEG	1483
Sharp	0630, 0869
Silva Schneider	0869
Sony	0864, 1033, 1069, 1070
Sylvania	0675
Symphonic	0675
Teac	0675, 0833, 1483
Telefunken	0833, 1483
Tevion	0833, 1483
Thomson	0551
Tom-Tec	0833
Toshiba	0503, 1854
TRANS-continentals	0833
United	0675
Universum	0869
Victor	1597
Zenith	0741, 0869

Wireless Link IR Code List		DVD
HD-DVD (Y)		
LG	0741	
Microsoft	2083	
Onkyo	1769	
RCA	1769	
Toshiba	1769	
Xbox	2083	
Wireless Link IR Code List		DVD
HDD/DVD Combination (Y)		
Airis	1321	
Blu:sens	1321	
Emerson	0675	
Go Video	1730	
GPX	0741	
Hitachi	1664	
Humax	1588	
JVC	0623, 1597	
LG	0741, 2135	
LifeOn	1416	
Mustek	1730	
NEC	0741	
Panasonic	0490, 1632	
Philips	0539, 1340, 2093	
Pioneer	0631	
Polaroid	2130	
RCA	0522	
Samsung	0490, 1635	
Sharp	0630, 1256, 1642	

Wireless Link IR Code List

HDD/DVD Combination (Y).....Continued

DVD

Sony	1033, 1069, 1070
Sylvania	0675
Tchibo	0741
TCM	0741
Thomson	0551
Toshiba	1503, 1510, 1588, 1639
Universum	0741
Victor	1597
Yamada	1416

Wireless Link IR Code List

Blu-ray Disc (Y)

BD

LG	0741
Panasonic	1641
Philips	2084
Pioneer	0142
Samsung	0199
Sharp	2250
Sony	1516, 2178, 2180